



$Y$  = CONTROL DIMENSION (mm)  
 $FLG.$  = FLANGE WIDTH (mm)  
 $e$  = SUPERELEVATION RATE ( %)

DECK OVERHANG TREATMENTS  
 (Superelevated Structures)  
 Figure 61-5A