

Bar Spacing (mm)																				
Bar Size	Area	100	110	120	130	140	150	160	170	180	190	200	225	250	275	300	325	350	400	450
#10	71	710	645	592	546	507	473	444	418	394	374	355	316	284	258	237	218	203	178	158
#13	129	1290	1173	1075	992	921	860	806	759	717	679	645	573	516	469	430	397	369	323	287
#16	199	1990	1809	1658	1531	1421	1327	1244	1171	1106	1047	995	884	796	724	663	612	569	498	442
#19	284	2840	2582	2367	2185	2029	1893	1775	1671	1578	1495	1420	1262	1136	1033	947	874	811	710	631
#22	387	3870	3518	3225	2977	2764	2580	2419	2276	2150	2037	1935	1720	1548	1407	1290	1191	1106	968	860
#25	510	5100	4636	4250	3923	3643	3400	3188	3000	2833	2684	2550	2267	2040	1855	1700	1569	1457	1275	1133
#29	645	6450	5864	5375	4962	4607	4300	4031	3794	3583	3395	3225	2867	2580	2345	2150	1985	1843	1613	1433
#32	819	8190	7445	6825	6300	5850	5460	5119	4818	4550	4311	4095	3640	3276	2978	2730	2520	2340	2048	1820
#36	1006	10060	9145	8383	7738	7186	6707	6288	5918	5589	5295	5030	4471	4024	3658	3353	3095	2874	2515	2236
#43	1452		13200	12100	11169	10371	9680	9075	8541	8067	7642	7260	6453	5808	5280	4840	4468	4149	3630	3227
#57	2581						17207	16131	15182	14339	13584	12905	11471	10324	9385	8603	7942	7374	6453	5736

REINFORCING BARS
Areas (mm²) Per One Meter Section

Figure 62-2B