



$$P_d = \frac{F_{DL}}{0.65H}$$

$$F_{DL} = \frac{3}{8} \gamma H^2 \frac{a}{g}$$

**DYNAMIC LATERAL EARTH PRESSURE DISTRIBUTION,
EXTERNAL STABILITY**

Figure 68-4D